

Range/Distance

Range 0...2.2 m
Rated operating distance S_n 2.2 m

Remarks

Order accessories separately.

For additional information, refer to user's guide.


Only for applications per NFPA 79 (machines with a supply voltage of maximum 600 V). Use an R/C (CYJV2) cable with suitable properties for attaching the device.

The sensor is functional again after the overload has been eliminated.

Connector Drawings



Wiring Diagrams



1) Emitter

Opto Symbols

