



### Basic features

<b>Basic standard</b>	IEC 60947-5-2
<b>Reference base unit</b>	BFB 75K-001-..
<b>Use</b>	for fiber optic base units BFB
<b>Version</b>	6x19, light grid

### Environmental conditions

<b>Ambient temperature</b>	-55...70 °C
<b>Ambient temperature connection area</b>	Acc. to fiber optic sensor
<b>Protection degree</b>	IP65

### Material

<b>Active surface, fiber arrangement</b>	Row
<b>Fiber type material</b>	PMMA
<b>Housing material</b>	Brass
<b>Material jacket</b>	PE
<b>Surface protection</b>	nickel plated

### Mechanical data

<b>Active surface, fibers</b>	Ø 0.25 mm (32x)
<b>Cable diameter D</b>	2.20 mm
<b>Cable length L</b>	2 m
<b>Cable, bending radius min.</b>	25 mm
<b>Cable, note</b>	can be trimmed
<b>Connection type</b>	Cable, 2.00 m, PE
<b>Dimension</b>	6 x 19 x 25 mm
<b>Fiber optic cable, structure</b>	Fiber bundle in plastic jacket
<b>Length B min., without bending</b>	20.00 mm
<b>Mounting</b>	Screw M3
<b>Tensile load max. at 20 °C</b>	6 N (max. 3s)

### Range/Distance

<b>Range</b>	100 mm
<b>Rated operating distance Sn</b>	100 mm
<b>Real switching distance sr</b>	100 mm

### Remarks

The cutting tool is included in the scope of delivery order other accessories separately.

Cut cable to length: use suitable cutting tool. Make a single cut, vertical to cable axis. The cut quality can affect the switching distance.

Reference object (target): gray card, 200 x 200, 90 % remission, axial approach.

Route fiber optic cable so that no excessive tensile, compression or torsional forces are permitted. Observe permissible bending radiuses. Installation may affect the switching distance.

## Opto Symbols

